

BATTERY OPTION CHART

Premium AGM	The Premium AGM is our highest quality battery. It requires no activation or maintenance and provides greater starting power and service life than the standard AGM and original equipment battery. No vent tube required.
Standard AGM	The Standard AGM features maintenance free power and service life. Activation is required. Acid included. No vent tube required.
Low Maintenance High Performance Dry	The equivalent to most vehicle's original equipment battery. It will match required power and maintenance schedule. Activation is required. Supplied with vent tube and acid pack.
Conventional Dry	Economy battery that requires increased maintenance. Activation is required. Supplied with vent tube and acid pack.

ACTIVATED/READY-TO-INSTALL			
PREMIUM AGM	STANDARD AGM	HIGH PERFORMANCE	CONVENTIONAL
ETX9	GTX9BS	---	---
ETX12	GTX12BS	---	---
ETX12	GTX12BS {56}	YB12BB2FP	---
ETX14	GTX14BS	---	---
ETX14 {64,67}	---	YB16BAFP	---
ETX14 {67}	---	YB16BA1FP	---
ETX14 {64,67}	YTX16BS1FP	---	---
ETX14 {67}	YTX16BSFP	CB16B	---
ETX14L	YTX14L-BS	---	---
ETX15 {76}	YTX14AHBSFP	YB14A2FP	---
ETX15 {76}	YTX14AHBSFP	CB14AA2	---
ETX15 {76}	---	YB14B2FP	---
ETX15 {76}	---	YB14AA1FP	---
ETX15L	YTX14AHLBSFP	CB14LA2	12N143AFP
ETX15L	---	YB14LB2FP	---
ETX15L {55}	---	SYB14LA2FP {65}	---
ETX15L {55}	---	SYB14LB2FP {65}	---
ETX15L {64}	---	YB14LA1FP	---
ETX16	YTX20BSFP	CB16B (LM)	---
ETX16 {67}	---	C60N24AFP	---
ETX16 {67}	---	YB16CBFP	---
ETX16L {74}	GTX20LBS	YB16HLALMFP	---
ETX16L {74}	YTX16LBSFP	CB16LB	12N163BFP
ETX16L {55}	---	SYB16LBFP {65}	---
ETX16L {120}	---	---	12N243FP
ETX16L {120}	---	---	12N243AFP
ETX16L {120}	---	C60N24ALBFP	---
ETX16L {67}	---	YB16CLBFP	---
ETX18L	YTX24HLBSFP	C50N18LA3	---
ETX18L {55,64}	---	SC50N18LATFP {65}	---
ETX18L {55,64}	YTX24HLBSFP {55,64}	SC50N18LATFP {65}	---
ETX18L {117}	---	C50N18AA	---
ETX18L {117}	YTX24HLBSFP {117}	C50N18AA	---
ETX18L {64}	---	C50N18LA3	---
ETX18L {64}	YTX24HLBSFP {64}	C50N18LA3	---
ETX20L	GTX20LBS	---	---
ETX20L	YTX20HLBSFP	---	---
ETX20L	GTX20LBS	CB18LA {56}	---
ETX30L	GTX30L	YB30LB	---
ETX30LA	---	YB30CLB	---
---	YTX20BSFP	YB18AFP	---
---	---	6YB112DFP	6N112DFP
---	---	CB5LBFP	12N53BFP
---	---	YB7AFP	12N74A
---	---	YB7LBFP	12N73BFP
---	---	CB9B	12N94B1FP
---	---	YB9LA2FP	12N93A1FP
---	---	CB9LB	12N93BFP
---	---	CB10LA2	12N103A2FP
---	---	YB10LBFP	12N103BFP
---	---	CB12AA	12N12A4A1FP

BATTERY FOOTNOTES

FOOTNOTES:

- {55} – Sensor NOT included with replacement battery. Disconnect sensor.
- {56} – Hold-down modifications may be necessary.
- {64} – Top and front terminal mounts only.
- {65} – Includes sensor not supplied with AGM.
- {67} – Supplied adapter may be required for proper fit.
- {76} – Shipped with 10mm adapter.
- {117} – Battery must be rotated for correct polarity. Hold-down modifications may be necessary. Top and front terminal mounts only.
- {120} – Shipped with 20mm adapter. Hold-down modifications may be necessary.